

## Software installation

Download the software from [www.rls.si/UPRGAM4096](http://www.rls.si/UPRGAM4096) by clicking the Documentation tab and selecting the file UPRGAM4096\_Software. Once downloaded open the Setup.exe file and follow the installation wizard to complete installation.

**NOTE:** You should install the UPRGAM4096 software BEFORE connecting the UPRGAM4096 interface.

Note: Administrator rights are required to install the software.

Compatible operating systems: Windows XP, Windows Vista, Windows 7, Windows 10


## Connecting the UPRGAM4096 interface and RMK4

After software installation connect the UPRGAM4096 to the computer using the USB cable.



### Connect the RMK4 as shown.

Make sure that the dot on the connector is on the same side as the square shaped pad on the RMK4.



Make sure that the slot on the interfaces is on the same side as the two ridges on the connector.



### Final assembly should look as shown




A **RENISHAW**  associate company


## Starting the AM4096 interface program

Start the program by clicking the Desktop icon  which has been created during installation or by selecting the program from the Start menu.

Once the application is started, you will see the following screen. Click the 'Power on' button.



The interface will now read the current programming / settings of the RMK4 and the screen should look something like this depending on the settings previously loaded.



During 'Power on' the interface reads the data stored inside the internal EEPROM of the AM4096 chip and the software interface displays the read information graphically.

## Programming and reading


The AM4096 can be re-programmed by changing the parameters within the software. Once the desired parameters have been selected, the 'PROG' button has to be clicked in order to save the changes to the chip.



The 'READ' button reads the current programming of the AM4096 chip. (If, for example, the parameters on the screen have been changed, but not saved, and the current programming needs to be read again, this can be done by pressing the 'READ' button.)

Different settings can be stored to the computer by pressing the 'SAVE' button. Previously saved settings can be uploaded by pressing the 'LOAD' button.


## Parameter description: FIRST COLUMN



### Refreshing data

The data from sensor can be refreshed continuously or manually. If data is refreshed continuously, the displayed position and other encoder data will constantly be refreshed whilst by **disabling the continuously refreshed** option the encoder data will only be refreshed once each time the user clicks the 'Refresh' button.


By default, the continuously refreshed option is enabled.



### Position display

The software displays the position as relative and absolute. By default, the Relative position displays the position as a number (e.g. 686/4096, where the first number represents the relative position and the second number represents the full number of counts, or the resolution the chip is set to). This can be changed to 'Degrees' and the display now shows the relative position in degrees.

*The Absolute position always shows the position as an absolute number.*



The position can also be displayed as a graphic form by ticking the 'Graphic representation' option.

### Tacho output

When the Tacho output is used, the Tacho section displays the speed in Hertz and RPM (rotations per minute).




### Magnet status

The 'Magnet status' section indicates whether the magnet is in range too close or too far. This helps control the distance between the magnet and the AM4096 chip.




### Automatic gain control (AGC gain)

The AGC gain section displays the percentage of the automatic gain control. When AGC is disabled the AGC gain is fixed at 50.0%. If the AGC is enabled, then the AGC gain varies, depending on the magnet to chip distance. See AGC section on how to enable or disable.




### Parameter description: SECOND COLUMN



### Chip address

In the Chip address section the address of the device can be set from 0 to 127. This is used when more devices are interconnected, where each device needs to have an individual address. Type a number from 0 to 127 into the text box and confirm by pressing the 'Set the new address' button.




See page 6 of the AM4096D01 datasheet for a detailed description of this functionality.

**NOTE – AM4096 chips with serial numbers AA3509 and AB3509 do not allow connecting more than one slave device to the TWI bus. This functionality is being added to the next revision of the product.**

The RMK4 default setting is '0'.

### Zero position

Zero position section user can set the relative zero position of the chip. The number represents the absolute position at which the relative zero position is (to be) set. There are two options to set the zero position of the chip:



**By pressing the 'Set zero position' button** virtual zero position will be set to the absolute zero position value inserted to the edit box. The value must be between 0 and resolution -1 otherwise an Error message will appear. E.g. with the resolution of 4096, the zero position value of 2048 will set the virtual zero position 180° to the absolute zero (note that the encoder position is displayed to the virtual zero position).

**By pressing the 'Zero' button**, current absolute position will be written to the zero position edit box and set the relative zero position according to the value. Therefore the displayed encoder position will be set to zero.

Any manual change of zero position value in the edit box has to be confirmed by clicking the 'Set zero position' button otherwise no change will be triggered (This is not the case for the change triggered by the 'Zero' button).

### Resolution

Here can be set resolution by selecting the required radio button. Resolution can be set to binary resolutions from 32 cpr (5 bit) to 4096 cpr (12 bit). It is in CPR (counts per revolution) or PPR (positions per revolution).

Resolution (Res)

4096    1024    256    64

2048    512    128    32

The RMK4 default setting is '4096' (12 bit).

### Digital hysteresis (Hyst)

Setting the digital hysteresis enables the user to prevent backcounting although also contributes to the overall measuring inaccuracy. Certain hysteresis value means that when switching the rotation direction encoder position will be frozen until the hysteresis angle is reached.

Digital hysteresis (Hyst)

0 (0.00°)

To set the hysteresis the user has to select the desired value (angle) from the drop box and click the 'set hysteresis' button.

### Regulator voltage

You can set regulator voltage if a power supply of 5 V is used, the 3.3 V option should be selected or if a power supply of 3 V is used, the 3 V option should be selected.

Regulator voltage (Reg35)

3.3 V    3 V

The RMK4 default setting is '3.3 V' (for 5 V power supply).

### Autonomous power down mode and Power down duty ratio (active : inactive)

In this part the power save mode can be enabled or disabled by selecting the appropriate button.

Autonomous power down mode (Pdee)

Disabled    Enabled

If enabled, the power down duty ratio can be selected. This means that the position is not read continuously, but in intervals as selected.

The RMK4 default setting is 'Disabled'.

Autonomous power down mode (Pdee)

Disabled    Enabled

Power down duty ratio (Pdtr) [active : inactive]

1:128    1:256    1:512    1:1024

### Bufsel and UVW – number of pole pairs

The output on pins 5, 6, 7 and 8 can be selected between UVW/Tacho and differential sinusoidal.

If the UVW outputs are selected, the number of pole pairs of the UVW commutation signals can be selected.

The RMK4 default setting is 'UVW, tacho dir' and the default number of pole pairs is 1.


Output function (BUFSEL)

UVW, tacho dir    Sinusoidal diff.

Number of pole pairs (UVW)

1    2    3    4    5    6    7    8

## Parameter description: THIRD COLUMN




### Outputs direction

Output direction can be selected to be either CW (clockwise) or CCW (counter clockwise). The RMK4 default setting is 'CW'.




### Vout/Tout pin function, DA data period and Tacho measuring range [Hz]

In this part the output on pin 20 can be selected between Linear voltage ('Vout') and Tacho ('Tacho').



If 'Vout' is selected, the period of the linear voltage output can be selected. See page 14 of the AM4096D01 datasheet for a detailed description of the Linear voltage output.



If 'Tacho' is selected, the measuring range can be selected (in Hz). See page 13 of the AM4096D01 datasheet for a detailed description of the Tacho output.

The RMK4 default setting is 'Vout' and the default period is '360°'. The default setting for the Tacho measuring range [Hz] is '2048'.

### SSI mode

Here you can select an operating mode of the SSI output. See page 11 of the AM4096D01 datasheet for a detailed description of this functionality.

The RMK4 default setting is 'Single data, no ring register'.



### AGC

You can select that AGC (automatic gain control) can be enabled or disabled.


The RMK4 default setting is 'Enabled'.



### Interpolator power

Here you can selected that the interpolator power can be enabled or disabled.


The RMK4 default setting is 'Enabled'.



### Incremental outputs


In this section the incremental outputs can be enabled or disabled.

The RMK4 default setting is 'Enabled'.




### Show display

For the purpose of presentations, the large analogue display panel was designed. The display can be shown by checking the 'show display' check box on the top of the main interface.




The analogue display enables the user to select one of the two display modes: the angular position display (by selecting the 'Position' radio button on the bottom) or the tachometer (the 'Tacho' radio button) which displays the rotating velocity in number of turns per second (Hz). The position display also enables resetting the position by clicking the 'RESET' button which acts the same way as the 'Zero' button on the main interface (see 'Zero position' section on the top).



Another display feature is the orange arrow on the very top left hand corner of the main interface. Pressing the arrow will reduce the main interface by hiding the operating board, and moving the digital position display to the top of the interface. Reduced interface can be combined with the analogue display so that the analogue display does not cover the main interface on the screen.

The original full-sized interface with the operating board can be restored by pressing the orange arrow on the reduced board.



**NOTE: All of the changes made will not be programmed to the encoder until the PROG button has been clicked.**

## Head office

---

### RLS merilna tehnika d.o.o.

Poslovna cona Žeje pri Komendi  
Pod vrbami 2  
SI-1218 Komenda  
Slovenia

**T** +386 1 5272100

**F** +386 1 5272129

**E** [mail@rls.si](mailto:mail@rls.si)

**www.rls.si**

## Document issues

Issue	Date	Page	Corrections made
1	20. 11. 2009	-	New document
2	25. 5. 2018	General	Software version: 2.1.0.3

This product is not designed or intended for use outside the environmental limitations and operating parameters expressly stated on the product's datasheet. Products are not designed or intended for use in medical, military, aerospace, automotive or oil & gas applications or any safety-critical applications where a failure of the product could cause severe environmental or property damage, personal injury or death. Any use in such applications must be specifically agreed to by seller in writing, and is subject to such additional terms as the seller may impose in its sole discretion. Use of products in such applications is at buyer's own risk, and buyer will indemnify and hold harmless seller and its affiliates against any liability, loss, damage or expense arising from such use. Information contained in this datasheet was derived from product testing under controlled laboratory conditions and data reported thereon is subject to the stated tolerances and variations, or if none are stated, then to tolerances and variations consistent with usual trade practices and testing methods. The product's performance outside of laboratory conditions, including when one or more operating parameters is at its maximum range, may not conform to the product's datasheet. Further, information in the product's datasheet does not reflect the performance of the product in any application, end-use or operating environment buyer or its customer may put the product to. Seller and its affiliates make no recommendation, warranty or representation as to the suitability of the product for buyer's application, use, end-product, process or combination with any other product or as to any results buyer or its customer might obtain in their use of the product. Buyer should use its own knowledge, judgment, expertise and testing in selecting the product for buyer's application, end-use and/or operating environment, and should not rely on any oral or written statement, representation, or samples made by seller or its affiliates for any purpose. EXCEPT FOR THE WARRANTIES EXPRESSLY SET FORTH IN THE SELLER'S TERMS AND CONDITIONS OF SALE, SELLER MAKES NO WARRANTY EXPRESS OR IMPLIED WITH RESPECT TO THE PRODUCT, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE, WHICH ARE DISCLAIMED AND EXCLUDED. All sales are subject to seller's exclusive terms and conditions of sale which, where the seller is (a) RLS merilna tehnika d.o.o., are available at <https://www.rls.si/customer-service>, (b) Renishaw, Inc., are available at <http://www.renishaw.com/Shop/legal/en/-42186>, or (c) another person, are available on request, and in each case, are incorporated herein by reference, and are the exclusive terms of sale. No other terms and conditions apply. Buyer is not authorized to make any statements or representations that expand upon or extend the environmental limitations and operating parameters of the products, or which imply permitted usage outside of that expressly stated on the datasheet or agreed to in writing by seller.

RLS merilna tehnika d.o.o. has made considerable effort to ensure the content of this document is correct at the date of publication but makes no warranties or representations regarding the content. RLS merilna tehnika d.o.o. excludes liability, howsoever arising, for any inaccuracies in this document. © 2018 RLS d.o.o.