


Installation drawing

RMB29AC01SS1 encoder module

Dimensions and tolerances in mm.



¹ When N-pole marks of the magnet actuator and the PCB are aligned sine output = mid level and cosine output = max. level.

² Not supplied. See page 3 in RMB29 data sheet for details.

³ See page 4 in RMB29 data sheet for options.