

# MS

# Incremental Magnetic Scales

ACCURACY UP TO ±10 μm/m

The robust MS incremental magnetic scales consist of a stainless steel carrier and an elastomer-bonded ferrite. The elasto-ferrite layer is magnetised with 2 mm, 2.032 mm or 5 mm long alternating magnetic poles that form an incremental magnetic pattern.







# **Features and benefits**

- Customer selectable position of reference mark
- Four accuracy grades available: ±10 μm/m, ±20 μm/m, ±40 μm/m, ±100 μm/m
- ► Partial arc application possibility
- Optional protective cover foil for heavy duty applications
- Excellent resistance to dirt, dust and humidity
- ► Easy installation with adhesive tape, end clamps or track section












# **General information**

The incremental RLS magnetic scales are compatible with RLS standard LM and component level RoLin readheads, which ensure reliable operation due to the non-contact design.

# Selection guide



	Pole	Scale		Compatibility with readheads						
Scale	length [mm]	width [mm]	Accuracy [µm/m]	LM10	LM13	LM15	RLB2	RLC2HD	RLC2IC	RLM2
MS05	2	5	±10 / ±20 / ±40	-	-	-	No Ri	No Ri	Ri+DCRM	Ri+DCRM
MS07	2.032	5	±40	-	-	-	-	-	-	Ri*
MS10	2	10	±10 / ±20 / ±40	Ri+DCRM	Ri+DCRM	-	-	-	-	-
MS12	2.032	10	±40	Ri*	Ri*	-	-	-	-	-
MS15	5	10	±100	-	-	Ri+DCRM	-	-	-	-

Ri - Unique and multiple reference mark or only incremental track available
No Ri - No unique and multiple reference mark option, only incremental track available
Ri+DCRM - Unique, multiple, distance-coded reference mark or only incremental track available

For readhead specifications see data sheets available at **RLS Media center**.

<sup>\*</sup> Compatible with DPI version only.



# Storage and handling

#### Storage temperature



-40 °C to +60 °C

## Operating temperature




Scale applied on the linear guide:  $-40 \, ^{\circ}\text{C}$  to  $+100 \, ^{\circ}\text{C}$ 

Scale applied on the curved surface: -40 °C to +80°C

## Humidity



High resistance to humidity



It is strongly recommended that the scale is factory cut at RLS or the product warranty does not apply.

The magnetic scale should not be exposed to magnetic field densities higher than 50 mT on its surface, as this may damage the scale.

#### Chemical resistance

The use of alcohol for cleaning is considered safe, but it is not allowed to immerse the scale in alcohol. Furthermore, the scale surface print and drawn reference mark may disappear if the scale is not carefully cleaned.

For more information on chemical resistance contact RLS.

### **Packaging**

The type of packaging depends on both the length of the magnetic scale and its accuracy class. Shorter scales are packed individually, while scales with a longer length are rolled.


To maintain accuracy, special packaging is used for magnetic scales of accuracy class D; Scales shorter than 1 m are packed in a plastic tube, while spiral packaging is used for longer lengths. This prevents demagnetisation of the scale by maintaining the distance between the scale rolls.

When option B, H or N is selected, the protective cover foil is supplied with the scale. The cover foil is not mounted on the scale.


All MS magnetic scales have 12 months shelf life and should be installed within this period.

# Magnetic scale design






# **Appearance and print**



The shape of the reference mark may vary. The image is for representation purposes only.

### Scale surface print description

Scale surface print appears every 100 mm and contains the RLS logo and a unique code.





# **Technical specifications**

# System data

Pole length		2 mm, 2.032 mm, 5 mm	
Reference mark		Unique, DCRM, multiple reference marks	
Scale accuracy*	Class A	±20 µm/m	
	Class B	±40 μm/m	
	Class C	±100 μm/m	
	Class D	±10 μm/m	

<sup>\*</sup>For more information about the accuracy please see the MST01 technical article at **RLS Media center**.

# Mechanical data

Material	Carrier	1.4310 stainless steel
	Magnetic scale	NBR elasto-ferrite
Thickness	Carrier	0.3 ±0.05 mm
	Double-sided acrylic adhesive tape VHB 3M9469	0.13 mm
	Cover foil	0.076 ±0.006 mm
	Double sided tape	0.05 mm
	Scale	1.43 ±0.1 mm (with back adhesive)
		1.3 ±0.1 mm (without back adhesive)
Mass	MS05, MS07	0.031 kg/m
	MS10, MS12, MS15	0.062 kg/m
Width	MS05, MS07	5 <sup>+0.15</sup> mm
	MS10, MS12, MS15	10 <sup>+0.15</sup> mm
Cover foil width	CF05 (MS05, MS07)	4.8 ±0.35 mm
	CF08 (MS10, MS12, MS15)	7.6 ±0.35 mm
	CF10 (MS10, MS12, MS15)	9.5 ±0.1 mm
Maximum length	Accuracy class A, B, C	50 m (150 m with longer lead time*)
	Accuracy class D	20 m
Expansion coefficie	ent (carrier)	~17 × 106 [m/mK]
Minimum bending	radius	75 mm
	·	

<sup>\*</sup>Not applicable for MS05 and MS07.


# **Environmental data**

Temperature	Operating	Scale applied on the linear guide: -40 °C to +100 °C
Scale		Scale applied on the curved surface: –40 °C to +80 °C
	Storage	-40 °C to +60 °C

# Reference mark options

# Unique reference mark

The readhead must be ordered with reference mark option A (see corresponding readhead data sheet). The magnetic scale must be ordered with reference mark (see **Part numbering**). If required, the cover foil can be installed over the reference mark. Magnetised reference mark will have a visible marking.



The shape and the position of the magnetised reference mark are critical so these options are only available as factory order.

# Multiple reference mark

The readhead must be ordered with reference mark option A (see corresponding readhead data sheet). The magnetic scale must be ordered with reference mark option P (see **Part numbering**). Multiple reference marks are magnetised, factory predefined and spaced every 50, 100, or 200 mm on a 20 m long scale. For custom options please **contact RLS**.

### Distance coded reference marks (DCRM)

The readhead must be ordered with reference mark option A (see corresponding readhead data sheet). The magnetic scale must be ordered with reference mark option D and a basic increment value specified as K (see **Part numbering**). The distance coded reference mark option provides multiple magnetised reference marks that are individually spaced according to a specific mathematical algorithm. The absolute position is calculated after traversing 2 consecutive reference marks. Maximum length and minimum traverse depend on basic spacing (K) between the reference marks, as shown in the figure below. which is customer selectable at point of order.

The basic increment K (in mm) is chosen at the point of order and must be divisible by 2 × P with no remainder. **K** determines: **Maximum codable length:** 

$$L_{\text{max}} = K \left( \frac{K}{2P} - 1 \right) - 2P$$

 $\mathbf{L}_{\text{max}}$  - Maximum codable length (in mm)


**K** - Basic increment (in mm)

**P** - Pole length (in mm)

**Minimum distance along the measuring scale** which needs to be traversed in order to calculate the absolute position. The minimum travel distance equals the basic increment **K - 2P**.



The distribution of the reference marks is shown in the figure below. DCRMs are produced by additional magnetisation of the magnetic scale.



<sup>\*</sup> Depends on magnetic scale length.

	Maximum codable length (n			
K (mm)	P = 2 mm	P = 5 mm		
20	76			
40	356			
60	836			
80	1,516			
100	2,396	890		
200	9,796	3,790		
300	22,196	8,690		
400	39,596	15,590		
500	61,996	24,490		
600	89,396	35,390		
700		48,290		
800		63,190		
900		80,090		
1,000		98,990		

There must be at least 3 reference marks on the scale.

**Basic increment (K in mm)** - Represents the distance in mm between odd reference marks; it determines the maximum codable length over which the absolute position can be defined. It also determines the minimum distance which needs to be traversed to capture 2 adjacent reference marks. The basic distance should be divisible by the length of 2 poles (in mm). K is customer selectable.

**Maximum codable length (L** $_{max}$  in mm) - Is the maximum length of the magnetic scale over which the DCRM feature can be applied and still provide a unique absolute position. Lengths shorter than the maximum length may be used (see Table 1).

**Pole length (P in mm)** - Is the length of a magnetised pole (S or N). We currently offer magnetic scales with pole lengths of 2 mm (MS10) and 5 mm (MS15).

#### How the absolute position is evaluated

The absolute position of the first traversed reference mark is calculated by the following formula:

$$RI1 = \left[\frac{1}{P} \times abs(2 \times \triangle RI - K) - sgn(2 \times \triangle RI - K) - 1\right] \times \frac{K}{2} + \left[sgn(2 \times \triangle RI - K) - sgn(D)\right] \times \frac{abs(\triangle RI)}{2}$$

#### Variables

**RI1** - Absolute position of first traversed reference mark (in mm)

**ΔRI** - Distance between two successively traversed reference marks (in mm)

 Basic increment between two fixed reference marks (in mm)

**D** - Direction of movement (+1 or -1)

#### **Operators**

**abs** - Absolute value

sgn - Sign function (+1 or -1)

### Timing of reference mark capturing

The minimum distance between 2 successive reference marks is eaqual to  $3 \times P$ . Subsequent electronics must be able to detect the position of 2 successive reference marks under the maximum speed condition. The minimum time for 2 successive reference marks to appear is given by the formula:

$$T_{Rimin} = \frac{3P}{v_{max}}$$

T<sub>Rimin</sub> - Minimum time between 2 successive reference marks (in ms)

P - Pole length (in mm)


v<sub>max</sub> - Maximum traverse speed (in m/s)

#### Periodic reference mark

The readhead must be ordered with reference mark option C (see corresponding readhead data sheet). The magnetic scale must be ordered without reference mark option (see **Part numbering**). The position information is output in incremental quadrature format with periodic reference pulses. The periodic reference pulses correspond to the magnetic pole length.

#### Stick-on reference mark

The readhead must be ordered with reference mark option A (see corresponding readhead data sheet). The magnetic scale must be ordered without reference mark option (see **Part numbering**). After the scale is installed, a reference mark sticker can be applied to the desired position on top of the scale using the reference mark applicator tool. Make sure that the reference mark sticker is aligned with the corresponding side of the readhead where the reference mark designator is located. It is recommended that the stick-on reference mark is applied for prototyping purposes only. As soon as the applications go to serial production, it is recommended to use a predefined magnetised reference mark. For the part number of the reference mark and applicatior tool, see Accessories on **page 27**.



Stick-on reference mark is only available for MS10 scale.



# Installation instructions

# Installation with adhesive tape

Applicable for MS05, MS07, MS10, MS12 and MS15

## **Installation surface preparation**

Magnetic scales can be equipped with VHB backside adhesive tape. Most substrates are best prepared by cleaning with a 50:50 mixture of isopropyl alcohol and water before applying the magnetic scale. Exceptions to the general procedure that may require additional surface preparation include:

- Heavy oil/grease: To remove heavy oil or grease from a surface, a degreaser or solvent-based cleaning agent may be required, followed by cleaning with IPA/water.
- Abrasion: Sanding a surface and then cleaning with IPA/water can remove heavy dirt or oxidation and improve adhesion.
- Adhesion promoters: Priming a surface can significantly improve initial and ultimate adhesion to many materials such as plastics and paints.
- Porous surfaces: Most porous and fibrous materials such as wood, chipboard, concrete, etc. must be sealed to provide
  a unified surface.
- Unique materials: Special surface preparation may be required for glass and glass-like materials, copper and coppercontaining metals, plastics or rubber containing migrating components (e.g. plasticisers).

Further information can be found online under "Surface Preparation for 3M™ VHB™ Tape Applications".

### **Scale application**


To simplify the scale installation use the scale applicator tool LMA10ASC00 with LM10/LM15 readhead or LM13ASC00 applicator tool with LM13 readhead. Mount the applicator tool to the readhead mounting bracket. Use two fasteners as per readhead mounting configuration.

Explainer video: Installation process using applicator tool for LM10/LM15


#### **Fastener mounting variants**

#### LM10 readhead with LMA10ASC00 applicator tool


0



#### LM13 readhead with LM13ASC00 applicator tool




Good surface contact can be achieved by applying a pressure of about 100 kPa. At room temperature, approximately 50 % of the final bond strength is achieved after 20 minutes, 90 % after 24 hours and 100 % after 72 hours. Dynamic overlap shear (peak force to separate is measured after 72 hours dwell time): 830 kPa.




# Load the scale into the applicator

Separate the backing paper from the first 40 mm of scale and feed the scale into the applicator tool.



#### Apply the scale.

not stick to the mounting surface until it outwards to each end. is in position. Attach the end of the scale to the mounting surface with light finger pressure.



#### Ensure complete adhesion.

Push the scale carefully through to the Apply firm finger pressure along the end of scale mark, ensuring that it does full length of the scale from the centre

To prevent the scale sticking to the mounting surface during this operation it may be necessary to re-apply approximately 20 mm of backing paper to the end of the scale before inserting through applicator tool.

Traverse the axis through its full travel at a slow, steady speed. While moving the axis apply a light pressure (with a finger) to the scale behind the applicator tool to attach it to the mounting surface and gently pull the backing paper away from the applicator tool as it is separated.

#### 4. Apply cover foil (if used).

Degrease the scale surface with alcohol and install as per scale installation instructions in step 3 onwards.


#### 5. Remove the applicator tool.

When the scale has been applied unbolt the applicator tool from the readhead mounting bracket.

Steps 6-10 apply for MS10 system only.

#### 6. Apply the stick-on reference mark (if used).

Place the LM10ARM00 reference mark applicator tool on scale in the correct orientation/required position along the length.






#### 9. Stick the reference mark on the scale.


Remove the backing paper from the reference mark sticker and carefully attach it to the surface of the scale by placing it next to the applicator tool.

Correct orientation of the reference mark is crucial. The mark on the sticker should be on the same side as the reference mark designators.



#### 10. Remove the stick-on reference mark applicator tool.

Remove the applicator tool leaving the reference mark sticker in the desired position.



Do not remove the scale for refitting or use elsewhere once it has been applied to the mounting surface. The scale can be applied only once.

# Partial arc installation

Applicable for MS05, MS07, MS10, MS12 and MS15

The minimum bending radius of the magnetic scale is 75 mm. It is advised using the end-clamps on both ends to prevent the scale from peeling off the surface.

Please note that installing the scale around the circular part will reduce the system total accuracy.


# Installation with end clamps

Applicable for MS10, MS12 and MS15

End clamp kit has been designed to anchor the ends of the MS magnetic scale. Make sure the installation surface is clean and free of debris. Included in the kit are 2 end clamps and 2 fasteners M2.5  $\times$  6 DIN 965.


#### **Installation process**

All dimensions are in mm.



#### Prepare the mounting surface.


Drill the holes to the mounting surface as shown above. Refer to the table below for the minimum distance of the reference mark from the edge.



#### Prepare the magnetic scale.

If the scale was not ordered pre-prepared for installation with end clamps, please make sure that:

- the hole to hole distance is correct (Scale length + 6 mm),
- the rubber surface at the ends of the scale was cut and removed as shown in the figure above.



#### Install the scale to the surface.

Make sure that the scale has been cut to the correct length and the mounting surface has been cleaned. Install the selfadhesive scale using the scale applicator tool.

# Install the end clamp.

Use the supplied fasteners and attach the end clamps so that the magnetic scale is held under the clamp.

# Magnetic scale Minimum distance of the reference mark from the edge MS10, MS15 13 mm MS12 10 mm

Magnetic scales can be mounted with end clamps only, without adhesive tape. However, in this case the mounting surface should be prepared for mounting. To prevent the magnetic scale from moving in the lateral axis, mill a 10 mm wide and >0.3 mm deep groove in the mounting surface.

If you mount the scale with end clamps only, without combining it with VHB, the recommended maximum length of the scale is 100 mm. End clamps are used to better fix the ends of the scale. We highly recommend to use both end clamps together with the VHB adhesive option.



#### **Installation with TRS**

Applicable for MS10 and MS15

TRS system is designed for applications that require an easily removable scale. The track system consists of aluminium guide rails, available in 1 m and 2 m sections, and a scale clamp element. It holds the magnetic scale securely while allowing it to expand and contract freely. The scale clamp provides a fixed point from which the MS scale can expand.

If damaged, the scale can be pulled out of the guide rails and replaced even if access is limited, reducing machine downtime. This feature also makes the system ideal for large machines that need to be disassembled for transport.

The design of the track section allows installation next to most standard guide rails or freely on any surface. This makes it suitable for many applications, such as automated assembly lines, packaging equipment, printing and other machines where the scale must be installed/removed for transport, or simply for all applications where the thermal expansion of the scale must be independent of the machine structure.


#### TRS technical specifications

Material	Aluminium, EN AW-6060
Mass	157 g/m
Thermal expansion	~25 µm/m/°C
Dimensions - cross section	20 mm × 4 mm
Available section lengths	1 m, 2 m

## **Installation tips**

#### Thermal expansion control

The scale can be fixed either at the left/right end or at the center depending on the thermal expansion scheme.




#### Alignment of different-level-substrate

The TRS system helps secure the level alignment of the scale across the whole axis.



#### **Example:** LM10 on MS10 scale with track system



- <sup>a</sup> ML = SL 10 mm
- <sup>b</sup> Minimum distance of reference mark from left edge
- <sup>c</sup> Minimum distance of reference mark from right edge

#### **Installation methods**

All dimensions are in mm.



Installation method 2
(see page 15)

(see page 16)

No reference surface available.


Reference surface available for alignment of track section.


Number of TRC00 (fasteners and washers) required


Track section	Installation method 1	Installation method 2
TRS100A00	8	4
TRS200A00	16	8



#### **Installation method 1**








A RENISHAW associate company

#### **Installation method 2**





# **Installation tolerances**

# Ride height

Values in mm.		LM10/LM13	LM15	RLB, RLC, RLM
o cover foil	No Ri	0.3 +1.2 -0.2	0.5 <sup>+3.5</sup> <sub>-0.4</sub>	0.3 +0.5 -0.2
	Magnetised Ri	0.3 +0.7 -0.2	0.5 <sup>+2.5</sup> <sub>-0.4</sub>	0.3 -0.2
	Stick-on Ri	0.6 0+0.4	-	-
ith cover foil	No Ri	0.3 +1.1 -0.2	0.5 <sup>+3.4</sup> <sub>-0.4</sub>	0.3 +0.4 -0.2
	Magnetised Ri	0.3 +0.6 -0.2	0.5 +2.4 -0.4	0.3 -0.2

# Lateral offset

Values in mm.	LM10/LM13	LM15	RLB, RLC, RLM
No Ri	0 ± 1	0 ± 1	005
Magnetised Ri	0 ± 0.7	0 ± 0.7	0 ± 0.5
Stick-on Ri	0 ± 1	-	-



### Roll

Values in °.	LM10/LM13/LM15	RLB, RLC2HD	RLM, RLC2IC*	
	±3	±2	±1	



# Pitch

Values in °.	LM10/LM13/LM15	RLB, RLC2HD	RLM, RLC2IC*	
	±3	±2	±1	



### Yaw

Values in °.	alues in °. LM10/LM13/LM15		RLM, RLC2IC*
	±3	±2	±1



# **Maximum speed tables**

# MS05, MS10

# Readheads LM10, RLB, RLC2HD, RLC2IC, RLM

Resolution [µm]	Counts / 2 mm				Maxi	mum speed	[m/s]			
≈ <b>0.244</b>	8,192	1.82	0.91	0.23	0.11	0.06	0.03	0.02	0.01	0.01
≈ <b>0.488</b>	4,096	3.65	1.82	0.46	0.23	0.12	0.06	0.05	0.02	0.01
≈ 0.976	2,048	7.30	3.65	0.91	0.46	0.24	0.12	0.10	0.05	0.02
1	2,000	7.47	3.73	0.93	0.47	0.24	0.12	0.10	0.05	0.02
1.25	1,600	9.33	4.67	1.17	0.58	0.30	0.16	0.12	0.06	0.03
≈ 1.953	1,024	14.58	7.30	1.82	0.91	0.48	0.24	0.19	0.10	0.05
2	1,000	14.93	7.47	1.87	0.93	0.49	0.25	0.20	0.10	0.05
2.5	800	18.67	9.33	2.34	1.17	0.61	0.31	0.25	0.12	0.06
≈ 3.906	512	29.17	14.58	3.65	1.82	0.95	0.49	0.38	0.19	0.10
4	500	29.87	14.93	3.73	1.87	0.97	0.50	0.39	0.20	0.10
5	400	37.33	18.67	4.67	2.34	1.22	0.62	0.49	0.25	0.12
6.25	320	46.67	23.33	5.84	2.91	1.52	0.78	0.61	0.31	0.16
≈ <b>7.812</b>	256	58.34	29.17	7.30	3.65	1.90	0.97	0.77	0.39	0.19
10	200	74.67	37.33	9.33	4.67	2.43	1.24	0.98	0.50	0.25
12.5	160	46.67	23.33	5.84	2.91	1.52	0.78	0.61	0.31	0.16
15.625	128	80.00	58.34	14.58	7.30	3.81	1.94	1.53	0.77	0.39
20	100	74.67	37.33	9.33	4.67	2.43	1.24	0.98	0.50	0.25
25	80	46.67	23.33	5.84	2.91	1.52	0.78	0.61	0.31	0.16
31.25	64	80.00	80.00	29.17	14.58	7.62	3.89	3.07	1.55	0.78
50	40	46.67	23.33	5.84	2.91	1.52	0.78	0.61	0.31	0.16
62.5	32	80.00	80.00	58.34	29.17	15.22	7.78	6.14	3.10	1.56
125	16	n/a	80.00	80.00	58.34	30.43	15.56	12.28	6.19	3.11
250	8	n/a	n/a	80.00	80.00	60.86	31.11	24.56	12.39	6.23
Minimum edge separation [µs]		0.07	0.13	0.50	1	2	4	5	10	20
Maximum count	frequency [MHz]	15	8	2	1	0.5	0.25	0.2	0.1	0.05
	Part numbering	K	Α	В	С	D	E	F	G	н



# MS05, MS10

# Readheads LM13 and LM13\_20 (high speed version)

Resolution [µm]	Counts / 2 mm		M	aximum spe	eed (values	in orange fo	or special o	otion 20) [m	/s]	
≈ 0.244	8,192	1.82	0.91	0.23	0.11	0.06	0.03	0.02	0.01	0.01
≈ 0.488	4,096	3.65	1.82	0.46	0.23	0.12	0.06	0.05	0.02	0.01
≈ 0.976	2,048	7.30	3.65	0.91	0.46	0.24	0.12	0.10	0.05	0.02
1	2,000	7.47	3.73	0.93	0.47	0.24	0.12	0.10	0.05	0.02
1.25	1,600	9.33	4.67	1.17	0.58	0.30	0.16	0.12	0.06	0.03
≈ 1.953	1,024	14.58	7.30	1.82	0.91	0.48	0.24	0.19	0.10	0.05
2	1,000	14.93	7.47	1.87	0.93	0.49	0.25	0.20	0.10	0.05
2.5	800	18.67	9.33	2.34	1.17	0.61	0.31	0.25	0.12	0.06
≈ 3.906	512	20 / 29.17	14.58	3.65	1.82	0.95	0.49	0.38	0.19	0.10
4	500	20 / 29.87	14.93	3.73	1.87	0.97	0.50	0.39	0.20	0.10
5	400	20 / 37.33	18.67	4.67	2.34	1.22	0.62	0.49	0.25	0.12
6.25	320	20 / 46.67	20 / 23.33	5.84	2.91	1.52	0.78	0.61	0.31	0.16
≈ 7.812	256	20 / 58.34	20 / 29.17	7.30	3.65	1.90	0.97	0.77	0.39	0.19
10	200	20 / 74.67	20 / 37.33	9.33	4.67	2.43	1.24	0.98	0.50	0.25
12.5	160	20 / 46.67	20 / 23.33	5.84	2.91	1.52	0.78	0.61	0.31	0.16
15.625	128	20 / 80	20 / 58.34	14.58	7.30	3.81	1.94	1.53	0.77	0.39
20	100	20 / 74.67	20 / 37.33	9.33	4.67	2.43	1.24	0.98	0.50	0.25
25	80	20 / 46.67	20 / 23.33	5.84	2.91	1.52	0.78	0.61	0.31	0.16
31.25	64	20 / 80	20 / 80	20 / 29.17	14.58	7.62	3.89	3.07	1.55	0.78
50	40	20 / 46.67	20 / 23.33	5.84	2.91	1.52	0.78	0.61	0.31	0.16
62.5	32	20 / 80	20 / 80	20 / 58.34	20 / 29.17	15.22	7.78	6.14	3.10	1.56
125	16	N/A	20 / 80	20 / 80	20 / 58.34	20 / 30.43	15.56	12.28	6.19	3.11
250	8	N/A	N/A	20 / 80	20 / 80	20 / 60.86	20 / 31.11	20 / 24.56	12.39	6.23
Minimum edge separation [µs]		0.07	0.13	0.50	1	2	4	5	10	20
Maximum count	frequency [MHz]	15	8	2	1	0.5	0.25	0.2	0.1	0.05
	Part numbering	K	Α	В	С	D	E	F	G	Н

# MS07, MS12

# Readhead LM13 (DPI), RLM (DPI)

Resolution [dpi]	Counts / 2 mm		Max	kimum speed [ı	m/s]	
25,600	2,048	4.11	1.03	0.52	0.25	0.13
25,000	2,000	4.23	1.06	0.53	0.25	0.13
20,000	1,600	5.28	1.32	0.66	0.31	0.16
12,800	1,024	8.24	2.05	1.03	0.49	0.25
12,500	1,000	8.45	2.11	1.06	0.50	0.26
10,000	800	10.57	2.63	1.32	0.63	0.32
6,400	512	16.50	4.11	1.59	0.98	0.50
6,250	500	16.91	4.23	2.11	1.01	0.52
5,000	400	21.13	5.28	2.63	1.26	0.64
4,000	320	25.00	6.60	3.30	1.57	0.81
3,200	256	25.00	8.24	4.11	1.95	1.01
2,500	200	25.00	10.57	5.28	2.50	1.29
2,000	160	25.00	6.60	3.30	1.64	0.81
1,600	128	25.00	16.50	8.24	3.92	2.00
1,250	100	25.00	10.57	5.28	2.50	1.29
1,000	80	25.00	6.60	3.30	1.64	0.81
800	64	25.00	25.00	16.50	7.85	4.02
500	40	25.00	6.60	3.30	1.57	0.81
400	32	25.00	25.00	25.00	15.72	8.05
200	16	N/A	25.00	25.00	25.00	16.09
100	8	N/A	25.00	25.00	25.00	25.00
Ede	ge separation [µs]	0.12	0.50	1	2	4
Cour	nt frequency [kHz]	8333	2000	1000	500	250




# MS15

### **Readhead LM15**


Resolution [µm]	Counts / 5 mm				Maxi	mum speed	[m/s]			
≈ 0.61	8,192	4.56	2.28	0.57	0.28	0.15	0.08	0.06	0.03	0.02
≈ 1.22	4,096	9.12	4.56	1.14	0.57	0.30	0.15	0.12	0.06	0.03
≈ <b>2.441</b>	2,048	18.24	9.12	2.28	1.14	0.59	0.30	0.24	0.12	0.06
2.5	2,000	18.68	9.32	2.33	1.17	0.61	0.31	0.25	0.12	0.06
3.125	1,600	23.32	11.68	2.92	1.46	0.76	0.39	0.31	0.15	0.08
≈ <b>4.882</b>	1,024	36.44	18.24	4.56	2.28	1.19	0.61	0.48	0.24	0.12
5	1,000	37.32	18.68	4.68	2.33	1.22	0.62	0.49	0.25	0.12
6.25	800	46.68	23.32	5.84	2.92	1.52	0.78	0.61	0.31	0.16
≈ 9.765	512	72.92	36.44	9.12	4.56	2.38	1.22	0.96	0.48	0.24
10	500	74.68	37.32	9.32	4.68	2.43	1.24	0.98	0.50	0.25
12.5	400	93.32	46.68	11.68	5.84	3.04	1.56	1.23	0.62	0.31
15.625	320	116.68	58.32	14.60	7.28	3.80	1.94	1.54	0.77	0.39
≈ 19.531	256	145.84	72.92	18.24	9.12	4.76	2.43	1.92	0.97	0.49
25	200	186.68	93.32	23.32	11.68	6.08	3.11	2.46	1.24	0.62
31.25	160	116.68	58.32	14.60	7.28	3.80	1.94	1.54	0.77	0.39
39.0625	128	200.00	145.84	36.44	18.24	9.52	4.86	3.84	1.94	0.97
50	100	186.68	93.32	23.32	11.68	6.08	3.11	2.46	1.24	0.62
62.5	80	116.68	58.32	14.60	7.28	3.80	1.94	1.54	0.77	0.39
78.125	64	200.00	200.00	72.92	36.44	19.04	9.72	7.67	3.87	1.95
125	40	116.68	58.32	14.60	7.28	3.80	1.94	1.54	0.77	0.39
156.25	32	200.00	200.00	145.84	72.92	38.04	19.45	15.35	7.74	3.89
312.5	16	n/a	200.00	200.00	145.84	76.08	38.89	30.70	15.48	7.78
625	8	n/a	n/a	200.00	200.00	152.16	77.78	61.40	30.97	15.56
Minimum edg	e separation [µs]	0.07	0.12	0.50	1	2	4	5	10	20
Maximum count	frequency [MHz]	15	8	2	1	0.5	0.25	0.2	0.1	0.05
	Part numbering	K	Α	В	С	D	E	F	G	н

# How to define scale length



Readhead	Α	В	С
LM10*	9 mm	Min. 10 mm	D – 20 mm
LM13*	7 mm	Min. 10 mm	D – 20 mm
LM15*	9 mm	Min. 10 mm	D – 20 mm
RLB	1 mm	-	D – 10 mm
RLC2HD	1 mm	-	D – 10 mm
RLC2IC	2 mm	Min. 8 mm	D – 16 mm
RLM	0	Min. 8 mm	D – 10 mm

# Installation of MS magnetic scale with end clamps



 $HHD = SL + (6 \text{ mm} \pm 1 \text{ mm})$ 

Measuring length with end clamps = SL - 26 mm

A - The minimum distance of the reference mark from the edge



# Part numbering

_	MS	10	В	1000	В	0032
Scale type						
<b>05</b> - 2 mm pole length, 5 mm width						
<b>07</b> - 2.032 mm pole length, 5 mm width						
<b>10</b> - 2 mm pole length, 10 mm width						
<b>12</b> - 2.032 mm pole length, 10 mm width						
<b>15</b> - 5 mm pole length, 10 mm width						
Accuracy class						
<b>A</b> - ±20 μm/m <b>C</b> - ±100 μm/m						
<b>B</b> - ±40 μm/m <b>D</b> - ±10 μm/m						
Scale length						
xxxx - xxxx equals scale length in cm						
See next page for scale length defining.	,					
Options						
A - VHB back adhesive tape (standard)						
<b>B</b> - VHB back adhesive tape; with cover foil *						
C - VHB back adhesive tape: ends prepared for end clamping						


- C VHB back adhesive tape; ends prepared for end clamping
- **G** No VHB back adhesive tape; sides prepared for insertion into track section
- H No VHB back adhesive tape, sides prepared for insertion into track section; with cover foil \*
- I No back adhesive tape
- N No back adhesive tape; with cover foil \*
- P No back adhesive tape; ends prepared for end clamping \*\*
- \* Cover foil is not factory mounted on the scale and must be ordered separately.
- \*\* It can only be used when the magnetic scale is installed in the groove to prevent lateral sliding. The groove dimension must correspond to the scale width.

#### Reference mark

- **0000** No reference mark
- Reference mark; xxxx equals position of reference mark in cm
  (Reference mark position will be within ±1 mm from requested position)
- Mxxx Reference mark; xxxx equals position of reference mark in mm (Reference mark position will be within ±1 mm from requested position)
- **Dxxx** Distance coded reference mark; xxx equals basic increment K
- Multiple reference marks in mm; xxx equals distance between magnetised reference marks in mm, factory predefined to 50 mm, 100mm and 200 mm.

  (each reference mark position will be within ±1 mm from requested position)

# Cover foil part numbering



xxxx - xxxx equals foil length in cm

Not all part number combinations are valid. Please refer to the table of available combinations on the next page.

# Table of available combinations

Series	Scale type	Accuracy class	Scale length	Options	Reference mark	
	05	A/B/D	xxxx / Mxxx	A/B/C/I/N/P	0000 / xxxx / Mxxx / Dxxx	
	07	В	xxxx / Mxxx		0000 / xxxx / Mxxx	
MS	10	A/B/D	xxxx / Mxxx		0000 / xxxx / Mxxx / Dxxx	
			2000	A/B/C/G/H/I	P050 / P100 / P200	
	12 B		xxxx / Mxxx	/ N / P	0000 / xxxx / Mxxx	
	15	С	xxxx / Mxxx		0000 / xxxx / Mxxx / Dxxx	



# **Accessories**





Stick-on reference mark **LM10SRM00** 



End clamp kit LM10ECL00

(2 clamps + 2 fasteners)



Applicator tool for stick-on reference mark **LM10ARM00** 



Magnet viewer MM0001



Applicator tool for magnetic scale and cover foil **LM10ASC00** 



Applicator tool for magnetic scale and cover foil **LM13ASC00** 



Track section, 1.00 m TRS100A00

(1x fastener M3x10 included)



Track section, 2.00 m TRS200A00

(1x fastener M3x10 included)



Fastener and washer **TRC00** 



Scale clamp with fasteners, 0.04 m
TRE004A00

(2x fastener M3x10 and 1x fastener M2x4 included)



#### Head office

#### RLS Merilna tehnika d.o.o.

Poslovna cona Žeje pri Komendi Pod vrbami 2 SI-1218 Komenda Slovenia

T +386 1 5272100 F +386 1 5272129 E mail@rls.si

www.rls.si

## Global support

Visit our website to contact your nearest sales representative.

#### **Document issues**

Issue	Date	Page	Description
1	3. 12. 2022	General	New document
2	11. 3. 2022	General	Cut reference removed, AS output removed,
			Installation tolerances amended, Installation
			with adhesive tape amended, Installation with
			end clamps amended, TRS drawings amended,
			Part numbering amended
3	22. 4. 2022	5	Width tolerance amended
		17	RLM roll, pitch, yaw tolerance amended

This product is not designed or intended for use outside the environmental limitations and operating parameters expressly stated on the product's datasheet. Products are not designed or intended for use in medical, military, aerospace, automotive or oil & gas applications or any safety-critical applications where a failure of the product could cause severe environmental or property damage, personal injury or death. Any use in such applications must be specifically agreed to by seller in writing, and is subject to such additional terms as the seller may impose in its sole discretion. Use of products in such applications is at buyer's own risk, and buyer will indemnify and hold harmless seller and its affiliates against any liability, loss, damage or expense arising from such use. Information contained in this datasheet was derived from product testing under controlled laboratory conditions and data reported thereon is subject to the stated tolerances and variations, or if none are stated, then to tolerances and variations consistent with usual trade practices and testing methods. The product's performance outside of laboratory conditions, including when one or more operating parameters is at its maximum range, may not conform to the product's datasheet. Further, information in the product's datasheet does not reflect the performance of the product in any application, end-use or operating environment buyer or its customer may put the product to. Seller and its affiliates make no recommendation, warranty or representation as to the suitability of the product for buyer's application, use, end-product, process or combination with any other product or as to any results buyer or its customer might obtain in their use of the product. Buyer should use its own knowledge, judgment, expertise and testing in selecting the product for buyer's application, end-use and/or operating environment, and should not rely on any oral or written statement, representation, or samples made by seller or its affiliates for any purpose. EXCEPT FOR THE WARRANTIES EXPRESSLY SET FORTH IN THE SELLER'S TERMS AND CONDITIONS OF SALE, SELLER MAKES NO WARRANTY EXPRESS OR IMPLIED WITH RESPECT TO THE PRODUCT, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE, WHICH ARE DISCLAIMED AND EXCLUDED. All sales are subject to seller's exclusive terms and conditions of sale which, where the seller is (a) RLS Merilna tehnika d.o.o., are available at https://www.rls.si/eng/salesterms, (b) Renishaw, Inc., are available at https://www.rls.si/eng/salesterms, (c) Renishaw, www.renishaw.com/legal/en/--42186, or (c) another person, are available on request, and in each case, are incorporated herein by reference, and are the exclusive terms of sale. No other terms and conditions apply. Buyer is not authorized to make any statements or representations that expand upon or extend the environmental limitations and  $operating\ parameters\ of\ the\ products,\ or\ which\ imply\ permitted\ usage\ outside\ of\ that\ expressly\ stated\ on\ the\ data sheet\ or\ agreed\ to\ in\ writing\ by\ seller.$ 

RLS Merilna tehnika d.o.o. has made considerable effort to ensure the content of this document is correct at the date of publication but makes no warranties or representations regarding the content. RLS Merilna tehnika d.o.o. excludes liability, howsoever arising, for any inaccuracies in this document.