

## **Orbis™** True Absolute Rotary encoder

Orbis<sup>™</sup> is a true absolute rotary encoder suitable for applications where a typical OnAxis encoder cannot be mounted at the end of the rotating shaft due to space limitations or where a hollow shaft is required. Orbis through-hole measuring principle allows customisation with various board and magnet sizes to suit your application. EASY INSTALLATION HIGH SPEED MULTITURN COUNTER





## **Features and benefits**

- True absolute
- 14 bit resolution
- Multiturn counter option
- Through-hole design
- Buit-in self-diagnostics

- Optional self-calibration after installation
- Integrated status LED
- BiSS C, SSI, SPI, Asynchronous serial and PWM communication interfaces
- Wide installation tolerances








## **General information**


The encoder consists of a diametrically magnetized permanent ring magnet and a printed circuit board. The geometrical arrangement of RLS' proprietary Hall sensors on the PCB enables the generation of one period of sine and cosine signals per mechanical magnetic revolution. In addition, it also allows cancelation of the third harmonic component.

An adaptive filtering function provides high resolution at low rotation speeds and low angular phase delay at high rotation speeds. Orbis also has an additional built-in self-calibration algorithm that improves the accuracy of the encoder after installation.



### Choose your Orbis absolute magnetic encoder system

### Orbis BR10 system





Max. 16 mm ID



Max. 22 mm ID



## Storage and handling

### Storage temperature



–40 °C to +105 °C

### **Operating temperature**



0 °C to +85 °C (standard) –40 °C to +105 °C (ETR)

н	um	id	itv



Up to 70 % non-condensing



### Readhead is ESD sensitive - handle with care.

Do not touch electronic circuit, wires or sensor area without proper ESD protection or outside of ESD controlled environment.

### **Chemical resistance**

RLS products are often used in industrial applications and exposed to chemicals that can affect their internal and external components. While our products are designed to be resistant to many harsh chemicals and environments, long-term resistance will depend on exposure, temperature, and concentration. Most chemicals our products are exposed to are not in continuous contact. Therefore, a material that might not be resistant when submerged in a chemical will last indefinitely when wiped down by that same chemical once a day.


For further information or to confirm compatibility with a chemical in your environment, contact RLS.

### Packaging


Less than 20 products are packed individually in an antistatic box. If the order quantity is 20 systems and larger, the parts are packed in antistatic plastic trays. Magnets and readheads are packed separately.

## Dimensions and installation drawings

### **BR10** Readhead




### **BR20** Readhead






### BM magnets and magnetic actuators

### Permanent magnet



#### Available magnets: OD ID Н 12 3 19 16 24 3.5 22 32 4 ID and OD tolerances are ±0.05.


### Magnetic actuator (magnet included)



ID	OD	н
6	21	9.5
8	21	9.5
10	22	9.5
12	27	10
14	27	10
15	27	10
20	34	12

ID tolerances are H7.

### Installation drawing




\* Shaft tolerance for application with magnetic actuator is g6.

Readhead should only be mounted on the gold plated surfaces around the mounting holes. Mounting surfaces should be parallel within 0.02 mm. See **Installation instructions**.

For recommended tightening torques, refer to the document TTD01 available at **<u>RLS Media center</u>**.

## **Installation instructions**

### Installation tolerances



Precise magnet and readhead installation is key to achieve good overall accuracy. The nominal axial ( $\Delta Z$ ) displacement applies when using a non-ferromagnetic shaft (aluminum, copper, plastic,...). When using a ferromagnetic shaft, the nominal axial displacement must be approximately 20 % to 30 % larger. For further information, **contact RLS**.

### Axial position adjustment (ride height)

Any non-magnetic and non-conductive tool can be used to mechanically check for correct ride height adjustment. The integrated LED can be used as a rough indicator. When the correct ride height is achieved, the LED will glow green and should not change colour as the magnet rotates.

### External magnetic field

The operating principle of any magnetic encoder is to sense changes in the magnetic field of the magnetic actuator. External magnetic fields generated by permanent magnets, electric motors, coils, magnetic brakes, etc. can affect the operation of the encoder. The accuracy of Orbis is degraded in the presence of magnetic field gradients in the axial direction.

### Self-calibration after installation

The self-calibration function eliminates eccentricity-related errors, which are a dominant contributor to the accuracy of the encoder and are caused by the eccentric mounting of the ring. This function eliminates the error of one sine wave per revolution. The self-calibration function can be triggered by the user via selected communication interfaces or via using the corresponding USB encoder interface.

For details, refer to the description of the selected communication interface. If the multiturn counter is used in the encoder and the rotational speed is higher than ±300 RPM, it may have an incorrect value after self-calibration. In this case the multiturn error flag is set.

Requirements:

- Free mechanical rotation for one full revolution (360°)
- Good signal over the entire calibration angle
- Maximum time available is 10 seconds
- Direction is not important
- Maximum speed during self-calibration up to 600 RPM
- Suitable communication interface or adapter that allows the function to be triggered
- Self-calibration must be started when no error is present (green LED)
- When using the SPI encoder version, LED must be visible to check the self-calibration status



## **Technical specifications**

System data		
Reading type		Axial reading
Resolution		14 bit
Repeatability		±2 LSB (counts, unidirectional)
Maximum speed		12,000 rpm
Accuracy		±0.25°, ±0.3° (BR20)
Accuracy thermal drift	BR10	±0.01°/°C
	BR10 ETR	- ±0.003°/°C
	BR20	10.0037 C
Digital hysteresis		±2 LSB (counts)
Position update rate		50 kHz
Electrical data		
Supply voltage		4.5 V to 5.5 V (at the connector)
Set-up time		100 ms (worst case: 200 ms)
Current consumption		Typ. 65 mA (no output load)
Connection		Molex 501568-1107 or soldering pads (through holes)
Output load	PWM, SPI	Max. ±5 mA at 3.3 V
	RS422	Max. ±100 mA at 5 V
ESD protection		HBM, max. ±2 kV
Mechanical data		
Mass	Readhead	5.3 g
	Magnetic	6 mm: 6.0 g; 8 mm: 5.5 g; 10 mm: 5.7 g; 12 mm: 8.7 g; 14 mm: 13.7 g
	actuator (ID)	15 mm: 7.1 g; 20 mm: 25 g
	Magnet (ID)	12 mm: 3.8 g; 16 mm: 6.4 g; 22 mm: 12.7 g
Magnet material		Neodymium with Ni-Cu-Ni protective layer
Actuator material		Anodised aluminium
Environmental d	ata	
Tomporature *	Operating	0 °C to +85 °C, -40 °C to +105 °C (BR10 ETR, BR20)
Temperature *	Storage	-40 °C to +105 °C
Humidity		0 % to 70 % non-condensing
External magnetic field		Max. ±3 mT (DC or AC) on top side of readhead
Shock		100 G (6 ms, standard EN 60068-2-27:2009)
Vibration		40 G (55 Hz – 2000 Hz, standard EN 60068-2-6:2008)


\* Not valid for cables with DSUB-9 connector.

## **Electrical connections**


Pin	Wire color	BiSS C	Asynchronous serial	PWM	SSI	SPI		
1	Brown							
2	-			5 V supply *				
3	White							
4	-		0 V (GND) *					
5	Pink			-				
6	Grey			-				
7	Red	MA+	RX command in+	Status out	Clock+	SCK		
8	Blue	MA-	RX command in–	-	Clock-	NCS		
9			Cable shield					
10	Green	SLO+	TX data out+	PWM out	Data+	MISO		
11	Yellow	SLO-	TX data out–	-	Data-	MOSI		

\* Pins are internally connected on PCB.

### Pinout



Cable shield (connected to pin 9)



Cable shield (connected to pin 9)



Readhead is ESD sensitive - handle with care.

Do not touch electronic circuit, wires or sensor area without proper ESD protection or outside of ESD controlled environment.



## **Status indicator LED**

LED		Status
	Green	Normal operation; position data is valid.
•	Orange	Warning; position is valid, but the resolution and/or accuracy might be out of specification. Some operating conditions are outside limits.
•	Red	Error; position data is not valid.
	Slow flashing	Communication has not been established. Position was not requested within last 200 ms. Color of flashing - see above.
0	No light	No power supply.
••••	Continuously fast flashing red	System error during start-up or operation.
3 s 3 s 3 s 3 s	3 sec. fast flashing	Self-calibration results - Refer to the documents BRD04 (Programming Orbis with Asynchronous serial interface) or BRD05 (Orbis BiSS C register access) available at <u>RLS</u> <u>Media center</u> .

The LED provides visual feedback of signal strength, error condition and is used for set-up and diagnostic use.

## **Multiturn counter**

Multiturn counter is available on the following communication interfaces: BiSS, Asynchronous serial (UART), SPI and SSI. Multiturn option is chosen with Resolution in **Part numbering**. Multiturn counter is 16 bit (0 to 65535 counts). Counting is available only when the encoder is powered, but the counter state is stored in a non-volatile memory at power-down and is restored at power-up. Maximum permissible rotation during power-down is  $\pm 90^{\circ}$ . If encoder is rotated for  $\pm 360^{\circ}$  or multiple rotations, this movement is not registered and also multiturn error is not set. If any other error is set during a  $90^{\circ}$  rotation or more, the multiturn counter value might become inconsistent with mechanical position.

### **Multiturn counter limitations**

Counter may have invalid value in following circumstances:

Possible reasons for failure	Solution			
If encoder is rotated for ±360° or multiple rotations during off state.	Use mechanical brake.			
If error flag (red LED) is present for 90° rotation or more.	Read and evaluate error bit.			
When encoder has moved for 90° or more or rotating at 300 RPM or more when encoder is performing blocking operation (saving information to non-volatile memory, factory reset, write protect, self-calibration).				
If user changes single-turn position offset for 90° or more.	Set new multiturn counter value right after setting zero position offset.			
If any function for saving information to non-volatile memory (save configuration, factory reset, write protect, self-calibration) is active when power-down happens.	Keep power supply stable when performing those operations.			

### Multiturn error flag

Error flag is set in one of the following conditions:

- Detected movement of >90° and <270° when powered off
- Detected speed of more than 300 RPM during blocking operation
- High, unexpected positional difference detected (acceleration error)

Multiturn error bit can be cleared by writting new multiturn counter value into the encoder or by power cycle. Clearing error bit on SSI interface requires power cycle.

### Battery powered multiturn counter

Orbis encoder can also be powered by external battery to keep counting the revolutions even when main power is not available. For further information regarding Orbis battery backup multiturn (BBM) refer to the document BRD08 available at **<u>RLS Media</u> <u>center</u>**.




## **BiSS C interface**

The encoder position, in 14 bit natural binary code, and the encoder status are available through the BiSS C protocol. The position data is left aligned. After the position data there are two status bits (active low) followed by CRC (inverted).


BiSS is implemented for point-to-point operation; multiple slaves are not supported.

### **Electrical connection**



\* The MA and SLO signals are 5 V RS422 compatible differential pairs. MA signal is terminated with RC (100  $\Omega$ , 1 nF) inside the encoder.

### **BiSS C timing diagram (single-turn)**



MA is idle high. Communication is initiated with first falling edge.

The encoder responds by setting SLO low on the second rising edge on MA.

When the encoder is ready for the next request cycle it indicates this to the master by setting SLO high. The absolute position and CRC data is in binary format, left aligned, MSB first.

### **Communication parameters**

Parameter	Symbol	Min	Тур	Мах	
MA period	t <sub>MA</sub>	200 ns		10 µs	
MA frequency	f <sub>MA</sub>	100 kHz		5 MHz	
ACK length	t <sub>ACK</sub>		5 bits		
Transfer timeout	t <sub>M</sub>		13.5 µs		
Pause time	t <sub>P</sub>	20 µs			

### Structure of data packet

Bit	b37 : b22	b21 : b8	b7 : b6	b5 : b0
Data length	16 bits	14 bits	2 bits	6 bits
Meaning	Multiturn counter (if specified in part number)	Encoder position	General status	CRC (inverted)

Encode	r position				
	<b>b37 : b22</b> Multiturn counter (if specified in part number) - Left aligned, MSB first.				
	b21 : b8	Encoder position – Left aligned, MSB first.			
Genera	l status				
	b7	Error - If low, the position data is not valid. Bits b21 - b8 are replaced with error status bits.			
	<b>b6</b> Warning - If low, the position data is valid, but some operating conditions are close to limits.				
		Error and Warning bits can be set at the same time, in this case the Error bit has priority. The colour of the LED on the readhead housing indicates the value of the General status bits. LED is flashing (duty cycle 50 %, frequency 2.5 Hz), when the encoder is in idle state. If the controller requests the data every 200 ms or more often, the duty cycle of the LED is 100 % (always on).			
CRC (inv	verted)				
	b5 : b0	Polynomial for CRC calculation of position, error and warning data is: $x6 + x1 + 1$ . Represented also as 0x43. Number must be inverted before comparison with calculated CRC.			

For further information regarding CRC calculation example, refer to the document CRCD01 available at RLS Media center.

#### **Error status** b21:b16 Reserved b15 Warning: Limit of lower ride height tolerance. Error: Signal amplitude too high. The readhead is too close to the magnet or an external magnetic field is present and too large. b14 Warning: Limit of upper ride height tolerance. Error: Signal amplitude low. The distance between the readhead and the ring is too large. b13 Warning: The readhead temperature is out of specified range. b12 Warning: Speed too high. b11 Error: Multiturn counter error. b10 : b8 Reserved.

For more information regarding BiSS protocol see **www.biss-interface.com**.

### **Encoder programming**

Encoder supports register access which allows setting position offset, multiturn counter, running self-calibration function, configuring the encoder, reading signal level indicator, temperature, detailed status bits and electronic datasheet. It also allows storing up to 4 kB of user data into the encoder (eg. motor parameters, assembly data or similar).


For further information regarding Orbis BiSS C register access, refer to the document BRD05 available at **RLS Media center**.



# Asynchronous serial communication interface over RS422 (UART)

Asynchronous serial communication is supported by a universal asynchronous receiver/transmitter commonly known as UART. It comprises two unidirectional communications channels, forming a full-duplex bidirectional data link. Every channel consists of a two wire differential twisted-pair connection conforming to the RS422 signalling standard.

### **Electrical connection**



Line signals		
RX+	RX data in +	
RX-	RX data in –	
TX+	TX data out +	
TX-	TX data out –	

\* The RX and TX signals are 5 V RS422 compatible differential pairs. RX signal is terminated with RC (100 Ω, 1 nF) inside the encoder.

### **Communication parameters**

Character length	8 bits
Parity	None
Stop bits	1
Flow control	None
Bit order	LSB first (standard)

Communication speed is set with the *Communication interface variant* in the part number:

Communication interface variant	А	В	С	D	E	F
Baud rate [kbps]	115.2	128	230.4	256	500	1000

### **Command set**

Command "	1" (0x31) – position request					
Response	1 byte ASCII "1" 2 bytes (4 for multiturn) hex – see Encoder position data structure					
Command "	3" (0x33) – short position request					
Response	2 bytes (4 for multiturn) hex – see Encoder position data structure					
Command "	d" (0x64) – position request + detailed status					
	1 byte ASCII "d"					
Response	2 bytes (4 for multiturn) hex – see Encoder position data structure					
	1 byte hex – see Detailed status data structure					
Command "	:" (0x74) – position request + temperature					
	1 byte ASCII "t"					
	2 bytes (4 for multiturn) hex – see Encoder position data structure					
Response	2 bytes hex – temperature (temperature of the readhead in °C multiplied by 10)					
	(Signed binary) Temperature of the sensor in (°C). This value is typically 10 °C to 15 °C higher than ambient.					
	Tolerance of the readout is ±5 °C.					

### Command "v" (0x76) – serial number

Response	1 byte ASCII "v"
	6 bytes ASCII – serial number

### Encoder position data structure

Encode	r position								
	b31 : b16	Multiturn counter (if specified in part number) - Left aligned, MSB first.							
	b15 : b2	<b>15 : b2</b> Encoder position – Left aligned, MSB first.							
Genera	l status								
	b1	Error - If low, the position data is not valid. The last valid position is sent out.							
	b0	Warning - If low, the position data is valid, but some operating conditions are close to limits.							
	The coloui cycle 50 %	Warning bits can be set at the same time, in this case the Error bit has priority. r of the LED on the readhead housing indicates the value of the General status bits. LED is flashing (duty n, frequency 2.5 Hz), when the encoder is in idle state. If the controller requests the data every 200 ms or n, the duty cycle of the LED is 100 % (always on).							
Detaile	d status								
	b7	Warning: Limit of lower ride height tolerance. Error: Signal amplitude too high. The readhead is too close to the magnet or an external magnetic field is present and too large.							
	b6	Warning: Limit of upper ride height tolerance. Error: Signal amplitude low. The distance between the readhead and the ring is too large.							
	b5	Warning: The readhead temperature is out of specified range.							
	b4	Warning: Speed too high.							
	b3	Error: Multiturn counter error.							
	b2 : b0	Reserved.							

### **Encoder programming**

Encoder supports changing default baud rate, position offset, multiturn counter, running self-calibration function, automatic transmission of selected data packet at programmable frame rate.

For further information regarding Programming encoders with Async serial interface can be found in the document BRD04, available for download at **RLS Media center**.

## 

## **PWM - Pulse width modulation interface**

The PWM interface transmits the information about the absolute angle position over the pulse width modulated PWM Out signal. An additional digital Status signal indicates the encoder's error condition.

### **Electrical connection**

The Status and PWM Out signals are 3.3 V LVTTL compatible. These signals have weak ESD protection. Handle with care. Maximum current sourced from or sunk into signal lines should not exceed 5 mA.

### **Status signal**

The Status signal indicates the current status of the encoder. The Status signal is high for normal operation and valid position information. The low state of the Status signal indicates an error state of the encoder which can be caused by:

- Operation outside the installation tolerances
- Sensor malfunction
- System error
- No power supply


When the Status signal is low, the PWM Out signal is low and no pulses are output.

The encoder position is latched on the rising edge of the PWM Out signal. The Status signal should also be checked at the rising edge of the PWM Out signal. If the Status signal changes during the PWM period, it does not affect the currently transmitted position information.

### **PWM Out signal**

The PWM Out is a pulse width modulated output with 14-bit resolution whose duty cycle is proportional to the measured position. The change of the pulse width by PWmin corresponds to a change in position by one count (change in angle for  $360^{\circ}$  /  $65536 \approx 0.00549^{\circ}$ ).

### PWM Out signal timing diagram



### **Communication parameters**

Communication interface variant in the part number defines the PWM frequency and all other dependent parameters.

		Communi	cation interfa	ace variant		
Parameter	Symbol	Α	D	E	Unit	Note
PWM frequency	f <sub>PWM</sub>	122.07	549.32	1098.63	Hz	
Signal period t <sub>PWM</sub>		8192	1820.44	910.22	μs	
Minimum pulse width	PW <sub>min</sub>	0.5	0.111	0.0556	μs	Position 0 (Angle 0°)
Maximum pulse width	PW <sub>max</sub>	8191.5	1820.33	910.17	μs	Position 16383
Min. counter frequency	f <sub>cntr</sub>	2	9	18	MHz	
Resolution		14	14	14	Bit	


Position [counts] = 
$$\frac{(t_{on} - PW_{min}) \times 16383}{PW_{max} - PW_{min}}$$



## SSI - Synchronous serial interface


The encoder position, in 14 bit natural binary code, and the encoder status are available through the SSI protocol. The position data is left aligned. After the position data there are two general status bits followed by the detailed status information.

### **Electrical connection**



\* The Clock and Data signals are 5 V RS422 compatible differential pairs. Clock signal is terminated with RC (100  $\Omega$ , 1 nF) inside the encoder.

### SSI timing diagram



The controller requests the position and status data of the encoder by sending a pulse train to the Clock input. The Clock signal always starts from high. The first falling edge of the Clock latches the last position data available and on the first rising edge of the Clock the most significant bit (MSB) of the position is transmitted to the Data output. The Data output should then be read on the following falling or rising edge. On subsequent rising edges of the Clock signal the next bits are transmitted.

After the transmission of the last bit the Data output goes to low. When the  $t_M$  time expires, the Data output goes high. The Clock signal must remain high for at least tP before the next reading can take place.

While reading the data, the half of a Clock period  $t_{CL}$  must always be less than  $t_{M}$ . However, reading the encoder position can be terminated at any time by setting the Clock signal to high for the duration of  $t_{M}$ .

### **Communication parameters**

Parameter	Symbol	Min	Тур	Мах
Clock period	t <sub>cL</sub>	2 µs (400 ns *)		15 µs
Clock frequency	f <sub>cL</sub>	70 kHz		500 kHz (2.5 MHz *)
Delay first clock	t <sub>FC</sub>	1.25 µs		13 µs
Transfer timeout	t <sub>M</sub>		14 µs	
Pause time	t <sub>P</sub>	20 µs		

\* With Delay First Clock function of the controller.

### Structure of data packet

Bit	b39 : b24	b23 : b10	b9 : b8	b7 : b0
Data length	16 bits	14 bits	2 bits	8 bits
Meaning	Multiturn counter (if specified in part number)	Encoder position	General status	Detailed status

Encoder posi	tion	
b39	:b24 Multit	urn counter (if specified in part number) - Left aligned, MSB first.
b23	:b10 Encod	er position – Left aligned, MSB first.
General state	us	
b9	Error	If high, the position data is not valid. The last valid position is sent out.
b8	Warni	ng - If high, the position data is valid, but some operating conditions are close to limits.
The cycl	colour of the e 50 %, freque	g bits can be set at the same time, in this case the Error bit has priority. LED on the readhead housing indicates the value of the General status bits. LED is flashing (duty ency 2.5 Hz), when the encoder is in idle state. If the controller requests the data every 200 ms of uty cycle of the LED is 100 % (always on).
Detailed stat	us	
b7		ng: Limit of lower ride height tolerance. Error: Signal amplitude too high. The readhead si too close magnet or external magnetic field is present and too large.
b6		ng: Limit of upper ride height tolerance. Error: Signal amplitude low. The distance between the ead and the ring is too large.
b5	Warni	ng: The readhead temperature is out of specified range.
b4	Warni	ng: Speed too high.
b3	Error:	Multiturn counter error.
b2 :	b0 Reser	ved.




## SPI - Serial peripheral interface


The Serial Peripheral Interface (SPI) bus is a four wire bidirectional synchronous serial communication interface, typically used for short distance communication. It operates in full duplex mode, where master (controller) selects the slave with NCS line, generates clock signal on SCK line, sends command over MOSI line and receives data over MISO line.

### **Electrical connection**

All data signals are 3.3 V LVTTL. Inputs are 5 V tolerant. Maximum current sourced or sunk from signal lines should not exceed 20 mA. Single-ended signals should be as short as possible, especially if high frequencies are used.



### SPI timing diagram



The controller starts communication by setting the NCS signal low. At the same time, the last available position data is latched. A delay of  $t_s$  is required to allow the encoder to prepare the data to be shifted to the output MISO on rising edges of the clock signal SCK. The command is received on 8 consecutive rising edges of SCK. Regardless of the command received, 16 bits of Position and General Status data (active low) are sent out. The following length of the requested data and the content depend on the command. The last eight bits contain CRC (inverted) of the complete data packet.

### **Communication parameters**

Parameter	Symbol	Min	Мах
Clock period	t <sub>cL</sub>	250 ns	
Clock frequency	f <sub>cL</sub>		4 MHz
Time after NCS low to first SCK rising edge	t <sub>s</sub>	2.5 μs for 14B resolution 8 μs for 14M resolution	
Pause time	t <sub>P</sub>	20 µs	
Frame rate			(1 / (ts + (Data length / fCL) + tp ) ) Hz

### Structure of data packet

Bit	b31 : b16	b15 : b2	b1 : b0	rN : r0	c7 : c0
Data length	16 bits	14 bits	2 bits	Variable	8 bits
Meaning	Multi-turn counter (if specified in part number)	Encoder position	General status	Requested data	CRC (inverted)

### **Encoder position - for all commands**

**b31 : b16** Multi-turn counter (if specified in part number) - Left aligned, MSB first.

**b15 : b2** Encoder position - Left aligned, MSB first.

### General status - for all commands

**b1** Error - If low, position data is not valid. Last valid position is sent out.

**b0** Warning - If low, position data is valid, but some operating conditions are close to limits.

Error and Warning bits can be set at the same time, in this case Error bit has priority.

The color of the LED on the readhead housing indicates the value of the General status bits. LED is flashing (duty cycle 50 %, frequency 2.5 Hz), when the encoder is in idle state. If the controller request the data every 20 ms or more often, the duty cycle of the LED is 100 % (always on).

### Requested data - Command "v" (0x76) - serial number request

r47 - r0 6 bytes (48 bits) of ASCII serial number.

### Requested data - Command "t" (0x74) - temperature request

r15 - r0 16 bits, signed. Number represents temperature of the readhead in °C multiplied by 10.

### Requested data - Command "d" (0x64) - detailed status request

r7	Warning: Limit of lower ride height tolerance. Error: Signal amplitude too high. The readhead is too close to the magnet or an external magnetic field is present and too large.
r6	Warning: Limit of upper ride height tolerance. Error: Signal amplitude low. The distance between the readhead and the ring is too large.
r5	Warning: The readhead temperature is out of specified range.
r4	Warning: Speed too high.
r3	Error: Multiturn counter error.
r2 - r0	Reserved.
CRC (inverted)	
c7 : c0	Polynomial for CRC calculation of the sent data is: $x8 + x7 + x4 + x2 + x1 + 1$ . Represented also as 0x97. Number must be inverted before comparison with calculated CRC.

For further information regarding CRC calculation example, refer to the document CRCD01 available at **RLS Media center**.



If command byte does not match any of listed commands, encoder will send only Position, Status, CRC data. If additional data is not required, MOSI line of the encoder should be tied to GND.

### **Encoder programming**

Encoder supports setting position offset, presetting multiturn counter value and running self-calibration function. For further information regarding programming encoders with SPI interface can be found in the document BRD09 available at **RLS media center**.

## Part numbering

### Readhead

	BR	10	SF	Α	14B	16	с	D	00
Series		-					-	-	
<b>BR</b> - Orbis board-level readhead									
<b>c</b> '									
Size									
<b>10</b> - Magnet type compatibility 12 and 16									
<b>20</b> - Magnet type compatibility 22									
Communication interface									
<b>DC</b> - BiSS C, RS422									
<b>PW</b> - Pulse Width Modulation (PWM), LVTTL									
<b>SC</b> - Synchronous serial interface (SSI), RS422									
<b>SF</b> - Asynchronous serial, RS422									
<b>SP</b> - SPI (Serial peripheral interface), LVTTL									
Communication interface variant									
See table next to the description of the chosen community	cation inte	rface for de	tailed infor	mation					
For <b>DC</b> : <b>D</b> - BiSS C, 5 ACK bits, bidirectional									
For <b>PW</b> : Base frequency in Hz:									
A D E									
122.07 549.32 1098.63									
For <b>SC</b> : <b>B</b> - Start bit and idle data line 1									
For <b>SF</b> : Link speed in kbps:									
A B C D E F									
R         B         C         B         L         I           115.2         128         230.4         256         500         1000									
For <b>SP: C</b> - Standard, full duplex									
Resolution									
<b>14B</b> - 14 bits per revolution									
<b>14M</b> - 14 bits per revolution + 16 bit multitur	n counte	r							
Magnet type compatibility									
<b>12</b> - BM120A190A1ABx00 or actuator BA060–	BA100								
16 - BM160B240A1ABx00 or actuator BA120-									
22 - BM220C320A1ABx00 or actuator BA200A		C							
Operating temperature range									
C - 0 °C to +85 °C (valid only for BR10)									
<b>D</b> 40 °C to +105 °C									
Connector option									
D - Molex 501568-1107									
<ul> <li>Molex 501568-1107</li> <li>H - Soldering pads with through holes</li> </ul>									
······································									
Special requirements									
<b>00</b> - No special requrements									

Not all part number combinations are valid. Refer to the table of available combinations on the following page.



### Table of available combinations

Series	Readhead size	Communication interface	Communication interface variant	Resolution	Magnet type compatibility	Operating temperature range	Connector option	Special requirements
		DC	P	14B				
		DC	D	14M				
		PW	A / D / E	14B				
		56	В	14B				
	10	SC	В	14M	12 / 16	C/D	D / H	00
		C.C.	A/B/C/D/	14B				
		SF	E/F	14M	22			
		SP	С	14B				
BR				14M				
DK	-	DC	D	14B		D		
				14M				
		PW	A / D / E	14B				
		SC	В	14B				
	20			14M				
		SF	A/B/C/D/	14B				
			E/F	14M				
		SP	С	14B				
		58	Ľ	14M				

### Magnet

	BM	220	С	320	Α	1	Α	В	Α	00
Series										
<b>BM</b> - Orbis magnet										
Inner diameter										
<b>120</b> - 12 mm										
<b>160</b> - 16 mm										
<b>220</b> - 22 mm										
Thickness										
<b>A</b> - 3 mm										
<b>B</b> - 3.5 mm										
<b>C</b> - 4 mm										
Outer diameter										
<b>190</b> - 19 mm										
<b>240</b> - 24 mm										
<b>320</b> - 32 mm										
Material										
A - NdFeB										
Grade										
<b>1</b> - Grade 1 tested magnet										
Surface finishing										
A - NiCuNi										
Temperature range										
<b>B</b> 40 °C to 120 °C										
De else nin n										
Packaging										
A - Standard packaging										
Special requirements										
<b>00</b> - No special requrements										

**00** - No special requrements

Not all part number combinations are valid. Refer to the table of available combinations below.

### Table of available combinations

Series	Inner diameter	Thickness	Outer diameter	Material	Grade	Surface finishing	Temperature range	Packaging	Special requirements
Series	ulainetei	THICKNESS	ulameter	wateriar	Glaue	misning	range	гаскаушу	requirements
	120	A	190						
BM	160	В	240	A	1	А	В	А	00
	220	С	320						



### **Magnetic actuator**

	BA	060	AB	01	Α	Α	00
Series							
<b>BA</b> - Orbis magnetic actuator							
Shaft diameter							
<b>060</b> - 6 mm							
<b>080</b> - 8 mm							
<b>100</b> - 10 mm							
<b>120</b> - 12 mm							
<b>140</b> - 14 mm							
<b>150</b> - 15 mm							
<b>200</b> - 20 mm							
Form							
AB - With 3 fasteners							
Magnet type							
<b>01</b> - BM120A190A1ABA00							
<b>02</b> - BM160B240A1ABA00							
<b>03</b> - BM220C320A1ABA00							
Material							
A - Anodized aluminium							
Packaging							
A - Standard packaging							
Special requirements							
00 - No special requirements							

00 - No special requrements

Not all part number combinations are valid. Refer to the table of available combinations below.

### Table of available combinations

Series	Shaft diameter	Form	Magnet type	Material	Packaging	Special requirements
	060					
	080		01		A	
	100					
BA	120	AB	02	А		00
	140					
	150					
	200		03			

## Accessories





Cable assembly, 1 m ACC048 ACC012

See chapter **<u>Cable assemblies</u>**.



Cable assembly, 3 m <u>ACC066</u> <u>ACC024</u>

See chapter **<u>Cable assemblies</u>**.



Cable assembly, 1 m ACC067 ACC027

See chapter **<u>Cable assemblies</u>**.



USB interface (for BiSS C communication interface) <u>E201-9B</u>



USB interface (For SSI communication interface) <u>E201-95</u>




Magnet viewer MM0001



### Cable assemblies

Cables with crimped connectors

Part number	Diameter	Length	Connector 1	Connector 2	Notes
ACC012		1.0 m		Their schools	Twisted pairs,
ACC024	5 mm	3.0 m		Flying leads	shielded, up to
ACC027		1.0 m	Molex 501330-	DSUB-9 M	+100 °C
ACC048		1.0 m	1100 and 501334- 0000		Twisted pairs,
ACC066	6.2 mm	3.0 m		Flying leads	shielded, up to
ACC067		1.0 m		DSUB-9 M	+75 °C



Connector 1	Connector 2			Asynchronous				
Pin nu	umber	Wire color	BiSS C	serial	PWM	SSI	SPI	
1	5	Brown		-				
2	-	-		5 V supply *				
3	9	White						
4	-	-	0 V (GND) *					
5	8	Pink			-			
6	4	Grey			-			
7	2	Red	MA+	RX command in+	Status out	Clock+	SCK	
8	3	Blue	MA-	RX command in–	-	Clock-	NCS	
9	1			Cable shi	eld			
10	6	Green	SLO+	TX data out+	PWM out	Data+	MISO	
11	7	Yellow	SLO-	TX data out–	-	Data-	MOSI	

\* Pins are internally connected on PCB.

### **Cable specifications**

Part numbers	ACC012, ACC024, ACC027	ACC048, ACC066, ACC067
Cable specifications	LI12YC12Y	LiYCY (TP)
Configuration	$4 \times 2 \times 0.14 \text{ mm}^2$	4 × 2 × 0.14 mm <sup>2</sup>
Rated voltage	250 V	350 V
Temperature range	Operating –30 °C to +100 °C Storage –40 °C to +105 °C Not valid for cables with DSUB-9 M connector.	Operating –40 °C to +75 °C (fixed) –5 °C to +70 °C (bending) Storage –40 °C to +80 °C
Environmental conformation	RoHS conform 73/23/EWG-Guideline CE conform Halogen free	RoHS and REACH compliant Flame-retardant according IEC 60332-1-2 Approvals based on VDE 0812 Classification ETIM 5.0 Class-ID: EC000104

ACC027 and ACC067 can be used for direct connection to E201-9S or E201-9B USB encoder interface. ACC012, ACC024 and ACC027 may be discontinued in future.



### Head office

### RLS Merilna tehnika d.o.o.

Poslovna cona Žeje pri Komendi Pod vrbami 2 SI-1218 Komenda Slovenia T +386 1 5272100F +386 1 5272129E mail@rls.si

### www.rls.si

### **Global support**

Visit our **website** to contact your nearest sales representative.

### **Document** issues

Date	Issue	Page	Description
18. 11. 2021	8	-	New design
		7, 27	Electrical connections table amended
1. 3. 2022	9	26-28	Cable assemblies amended
2. 6. 2022	10	4, 24, 25	Packaging information amended

This product is not designed or intended for use outside the environmental limitations and operating parameters expressly stated on the product's datasheet. Products are not designed or intended for use in medical, military, aerospace, automotive or oil & gas applications or any safety-critical applications where a failure of the product could cause severe environmental or property damage, personal injury or death. Any use in such applications must be specifically agreed to by seller in writing, and is subject to such additional terms as the seller may impose in its sole discretion. Use of products in such applications is at buyer's own risk, and buyer will indemnify and hold harmless seller and its affiliates against any liability, loss, damage or expense arising from such use. Information contained in this datasheet was derived from product testing under controlled laboratory conditions and data reported thereon is subject to the stated tolerances and variations, or if none are stated, then to tolerances and variations consistent with usual trade practices and testing methods. The product's performance outside of laboratory conditions, including when one or more operating parameters is at its maximum range, may not conform to the product's datasheet. Further, information in the product's datasheet does not reflect the performance of the product in any application, end-use or operating environment buyer or its customer may put the product to. Seller and its affiliates make no recommendation, warranty or representation as to the suitability of the product for buyer's application, use, end-product, process or combination with any other product or as to any results buyer or its customer might obtain in their use of the product. Buyer should use its own knowledge, judgment, expertise and testing in selecting the product for buyer's application, end-use and/or operating environment, and should not rely on any oral or written statement, representation, or samples made by seller or its affiliates for any purpose. EXCEPT FOR THE WARRANTIES EXPRESSLY SET FORTH IN THE SELLER'S TERMS AND CONDITIONS OF SALE, SELLER MAKES NO WARRANTY EXPRESS OR IMPLIED WITH RESPECT TO THE PRODUCT, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE, WHICH ARE DISCLAIMED AND EXCLUDED. All sales are subject to seller's exclusive terms and conditions of sale which, where the seller is (a) RLS Merilna tehnika d.o.o., are available at https://www.rls.si/eng/salesterms, (b) Renishaw, Inc., are available at https:// www.renishaw.com/legal/en/--42186, or (c) another person, are available on request, and in each case, are incorporated herein by reference, and are the exclusive terms of sale. No other terms and conditions apply. Buyer is not authorized to make any statements or representations that expand upon or extend the environmental limitations and operating parameters of the products, or which imply permitted usage outside of that expressly stated on the datasheet or agreed to in writing by seller.

RLS Merilna tehnika d.o.o. has made considerable effort to ensure the content of this document is correct at the date of publication but makes no warranties or representations regarding the content. RLS Merilna tehnika d.o.o. excludes liability, howsoever arising, for any inaccuracies in this document. © 2022 RLS d.o.o.